


How to Use Diamond Drill Bits



NEVER start drill at a 90 degree angle
Start drilling hole at a 45 degree angle



Once hole is started, oscillate drill in a circular motion



Dip drill bit in a cup of water after every 5 seconds of drilling

Diamond Drill Bit Requirements and Specifications

Wear proper PPE.
Drilling creates dust- do not breathe dust from drilling. Silica exposure from drilling is dangerous and can cause respiratory problems.

Use the bit only to cut the intended materials which are: Porcelain, Ceramic tile and natural stone.



Not for use with a hammer drill.



no hammer drill!

Drill Bit (3/16" to 1/2")	2400rpm MAX	drill mount 3/8" shank	Wet Use	Dry Use	porcelain glass stone
-------------------------------------	----------------	---------------------------------	------------	------------	-----------------------------

Drill Bit (5/8" to 5 1/2")	12500rpm MAX	angle grinder mount 5/8" x 11 thread	Wet Use	Dry Use	porcelain glass stone
--------------------------------------	-----------------	--	------------	------------	-----------------------------

*Adaptor available for drill

Porcelain Taper Bit	2400rpm MAX	angle grinder mount 5/8" x 11 thread	Wet Use	Dry Use	porcelain glass stone
----------------------------	----------------	--	------------	------------	-----------------------------

*Adaptor available for drill